



THE WAY TO PLAY.

WARRANTY

FACTORY

388 Millcreek Rd
Bird in hand, PA 17505
(717) 394-4711
(717) 394-4266 fax

HEADQUARTERS

9325 South Georgia St
Amarillo, TX 79118
(806) 353-2570

WWW.ADVENTUREWORLDPLAYSETS.COM

1 YEAR WARRANTY

No questions asked! If anything on your swing set breaks, fades, or affects the integrity of the swing set, we will send a crew out (within 200 miles of any of our warehouses) to fix the issue. The only exception is willful damage, normal wear and tear, or an act of God. If you are located farther than 200 miles from our closest warehouse, we will ship the part to the closest dealer or directly to your house.

5 YEAR WARRANTY

Your swings, slides and accessories are guaranteed against manufacturer defects. We will send the part to the closest dealer in your area.*

20 YEAR WARRANTY

Your swing set frame is guaranteed against manufacturer defects. We will send the part to your closest dealer.*

* If you don't live close to a dealer, pay for the shipping, and the part will arrive at your house.



THE WAY TO PLAY.

MAINTENANCE INSTRUCTIONS

FACTORY

388 Millcreek Rd
Bird in hand, PA 17505
(717) 394-4711
(717) 394-4266 fax

HEADQUARTERS

9325 South Georgia St
Amarillo, TX 79118
(806) 353-2570

WWW.ADVENTUREWORLDPLAYSETS.COM

At the beginning of each play season:

- Tighten all hardware.
- Check all moving parts including swing seats, ropes and chains for wear, rust, or other deterioration. Replace as needed.
- Check metal parts for rust. If found, sand and repaint using a non-lead-based paint. Avoid getting paint on vinyl or plastic parts.
- Reinstall any plastic parts, such as swing seats or any other items that were removed for the winter months.
- Rate and check depth of loose fill protective surface materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

Once a month during play season:

- Lubricate all metallic moving parts per manufacturer's instructions.
- Check all moving parts including swing seats, ropes and chains for wear, rust or other deterioration. Replace as needed.



THE WAY TO PLAY.

MAINTENANCE INSTRUCTIONS

FACTORY

388 Millcreek Rd
Bird in hand, PA 17505
(717) 394-4711
(717) 394-4266 fax

HEADQUARTERS

9325 South Georgia St
Amarillo, TX 79118
(806) 353-2570

WWW.ADVENTUREWORLDPLAYSETS.COM

Twice a month during play season::

- Tighten all hardware.
- Check all protective covering on bolts, pipes, edges and corners. Replace if they are loose, cracked or missing.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

At the end of each play season or when the temperature drops below 20 degrees F:

- Remove plastic swing seats and other items as specified by the manufacturer and take indoors or do not use.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.



THE WAY TO PLAY.

SAFETY

FACTORY

388 Millcreek Rd
Bird in hand, PA 17505
(717) 394-4711
(717) 394-4266 fax

HEADQUARTERS

9325 South Georgia St
Amarillo, TX 79118
(806) 353-2570

WWW.ADVENTUREWORLDPLAYSETS.COM

FOR YOUR CHILDREN'S SAFETY:

Keep play set area free from trees, boulders, wires, fences, other obstacles, insects or rodents.

Replace any broken/missing parts before next use. Contact your local dealer for any repair issues.

Cleaning Recommendations: Clean, wash-off using a garden hose, use glass cleaner if necessary. If bleach is used – make a 10% bleach to water solution. Wipe off & rinse with water immediately.

DO NOT:

Leave children unattended when playing on play set.

Paint, caulk, or varnish your play set.

Use playset if any pieces are missing or broken.

Strike or hit any vinyl or plastic with a hard object which may cause damage to the product.

Allow children to play on or near before installation is complete.

DO:

Hug your children every day and remember to supervise them when they play!